

Full Pit toilet Stanger KZN – 2007 case study



Full Pit toilet day of dosing



Two days after dosing smell gone



Four days after dosing level has dropped



Six days after dosing the level has dropped by half metre



Ten days after dosing the level has dropped by one metre